Wireless Presentation Adaptor

User's Manual

(Model Name: WPS-II Wifi Adapter)

Version: 2.0

Date: Aug. 01, 2011

Table of Contents

1. Overview 4
2. Quick Start 6
3. Windows Client Utility 9
3.1 Starting Program 9
3.2 Login 10
3.3 Main User Interface 11
3.4 Screen Projection 11
3.5 Menu Description 12
3.5.1 Show Login Code 12
3.5.2 Open Admin Web Page 13
3.5.3 Searching Server 13
3.5.4 Projection Quality 14
3.5.5 Projection Source 14
3.5.6 Quick connection 15
3.5.7 Auto WiFi Connect 15
3.5.8 Auto Power Manager 16
3.5.9 Hide UI 16
3.5.10 Advanced Screen Capture 17
3.5.11 Make WPS Token 18
3.5.12 Copy Application to desktop 19
3.5.13 Hot Key 19
3.5.14 About 20
3.5.15 Exit 20
4. Mac Client Utility 21
4.1 Launch Application 21
4.2 Main User Interface 22
4.3 Screen Projection 22
5. Web Management 23
5.1 Home Page 23
5.2 Download Software 24
5.3 Login Web Admin 25
5.3.1 System Status 26
5.3.2 Network Setup 27
5.3.3 OSD Setup 29
5.3.4 Projection Setup 30
5.3.5 Change Passwords 31

5.3.6 Reset to Default 31
5.3.7 Firmware Upgrade 32
5.3.8 Reboot System 33
5.3.9 Logout 34
6. Appendix 35
Screen Image Background Maker 35

1. Overview

WPS-Dongle is a must-have device for your meeting room! It turns your existing "wired" projector into a "high-end wireless" projector. With the revolutionary Plug-and-Show wireless projection features, WPS makes every of your presentation and meeting efficient and successful.

- High Performance Wireless Projection

With the revolutionary high performance wireless projection, you can easily share the multimedia on the big monitor with friends without cable hassle.

- High Performance Wireless Projection & Audio Projection

With the revolutionary high performance wireless projection with audio, you can easily share the multimedia on the big monitor with friends without cable hassle.

- Easy installation

Download the software from web management page directly, or make a “Plug & Show” token to project wirelessly right away

- Plug & Show

There is an easy tool to make a Plug & Show USB Token on UI menu. Just link your PC/Laptop to WPS (through WLAN or Ethernet), plug the token into a USB port, and in seconds, your screen will be wireless projected to the connected projector!

- Macintosh (Mac) wireless Projection

WPS-Dongle supports Mac client connected and projected wirelessly. By launching the Mac client software which can be downloaded from the web management page, WPS provide the same experience to Mac user to utilize the wireless presentation feature.

- 4-to-1 Split Screen Projection

With this 4-to-1 split screen feature, up to four PC screens can be projected to one projector in the same time. Thus you can easily do side-by-side comparison from four PC / PDAs to increase meeting productivity!

- Smartphone wireless projection

WPS-Dongle supports MobiShow function for windows mobile 5/6 system. By launching MobiShow utility, MobiShow brings your mobile screen to big screen and which can play photos and PtG files stored in your mobile phone for presentation.

- Change Standby Screen

You can use the application “Screen Image Background Maker” to change the Splash Screen. Design the image with message you would like to present, upload it through web control page, and you could have customized starting page.

- AP Client Mode

You can enable the AP-Client Mode function to let WPS join the existing Access Point through Wi-Fi. This feature provides the flexibility of wireless network deployment in enterprise environment.

- Support PoVGA

Connect WPS-Dongle to a projector supporting PoVGA, the power can be supplied directly from the VGA port without external power adapter.

➢ Features

- Support Windows Win7, Vista, XP.
- Support Macintosh (Mac) version 10.5 and above.
- Plug and Show! No installation required … just plug in the accompanied token to a USB port, and hassle free presentation can be started in seconds.
- 4-to-1 split screen projection! Turn one projector into four, increase meeting productivity right away.
- Smartphone wireless projection! PC-less stylish presentation becomes possible!
- Provide session security login, wireless WEP/WPA key and Gatekeeper function to protect presentation contents and keep good security to office networks.
- Support High Performance screen projection
- Changeable Splash Screen image!
- SNMP Manager! To manage the devices easily
- AP-Client Mode! Deploy wireless network in enterprise environment easily
- Support PoVGA.

2. Quick Start

1) Please plug WPS-Dongle into projector VGA port, and turn on the projectors power to use.



2) urn on WPS Dongle.

- When Projector shows the default menu on the screen as below, it indicates the WPS dongle is ready.

LOGIN CODE: 1234
Wireless Presentation System
WPS-Dongle 2
Quick Guide
1. Make sure your WLAN is enabled, and connect to Wireless Presentation System.
2. Open your browser, or enter the IP address (refer to below server IP address)
3. Click on "Download", and execute the installation program.
4. Make sure your personal firewall allows WPS software to pass through!
5. Enter the LOGIN CODE to start projection!
PoVGA
SSID : WPS-Dongle2
Server IP : 192.168.100.10
Channel : 2
Securrity : None
Resolution : 1024 x 768
Version : 0.0.2.0

3) Make sure your PC WLAN is enabled already, and connect your PC with WPS Dongle.
4) Open your browser and enter the IP address to access the WPS web home page.
   - The default IP address of WPS is **192.168.100.10** or refers to the IP address shown on the left corner of projector screen.



5) Download the client software. Please select the" Win7 / Windows Vista / XP "

or ”MAC” and execute the installation program.

After installing the program, you will see the WPS shortcut on the PC screen.




File Download - Security Warning
Do you want to run or save this file?
Name: WPS.exe
Type: Application, 1.36MB
From: 192.168.100.10
Run
Save
Cancel
While files from the Internet can be useful, this file type can potentially harm your computer. If you do not trust the source, do not run or save this software. What's the risk?

6) Make sure your personal firewall allows WPS software to pass through.
7) Select device that your want to projection



8) Enter the **LOGIN CODE** , you can see the login code on the projector screen.

9) Click the "**Play**" button to start projection!

3. Windows Client Utility

3.1 Starting Program

After you download WPS Windows program via web page successfully, then follow below steps to start.

1) Click WPS icon to execute the program.

2) Program start to search for WPS dongle automatically,
3) If WPS dongle found then "**Login Code**" dialog dongle will be pop up on the PC screen.

- **Searching for WPS dongle**

- **WPS dongle is founded and enter login code to start.**



3.2 Login

1) After “Login Code” dialog dongle shown, enter login code to start presentation.
2) You can see the login code shown on the projector screen.



3.3 Main User Interface



3.4 Screen Projection

Click the “Play” button for full or split screen, you can project the main screen on to the display immediately, click the “Pause” button, you can freeze you projection screen, click the “Stop” button to stop projecting your screen, by clicking speedy mode button, the projection will enter speedy mode for faster projection.

*. 4-1 function will be disabled in speedy mode.

Button	Description
	Full Screen projection
	Project to Split #1
	Project to Split #2

	Project to Split #3
	Project to Split #4
	Stop projecting
	Pause projecting

3.5 Menu Description



3.5.1 Show Login Code

Click **“Show Login Code”**, it will display the login code on the right-upper of desktop and close it automatically after 10 seconds. You can also click on the area to close this window manually.





3.5.2 Open Admin Web Page

Click to open function menu and select **“Web Admin”** management web page. The web page detailed functions will be described on next chapter.





3.5.3 Searching Server

Click **“Search Server”** to re-search the WPS again.



3.5.4 Projection Quality

Click the **“Projection Quality”**, you can select to project the Normal or Best for projection wording quality,



3.5.5 Projection Source

Click the **“Projection Source”**, you can select to project the main screen of desktop or the virtual extended screen.



P.S: Virtual Extended Screen option

You need to install “VDD.exe” driver first which is stored in the USB token.

Note: Unsupported Win7 starter.

3.5.6 Quick connection

Click **“Quick connection”** to enable connect the last connection directly



3.5.7 Auto WiFi Connect

Click **“Auto WiFi Connect”** to enable the auto WiFi discovery and connection function for quick wireless set up.



3.5.8 Auto Power Manager

To make the highest projection performance, application will turn the PC's windows power scheme from current settings to "highest performance", however, you can click the **"Auto Power Manage"** to enable or disable this function and restore you power scheme immediately.



3.5.9 Hide UI

Click the **"Hide UI"**, you can choose to hide or display the application control panel from projection screen.



3.5.10 Advanced Screen Capture

Click the **“Advanced Screen Capture”**, you will be able to see tip windows and other layered windows (include the main UI) on the connected display.
However, the mouse cursor may blink from time to time when you are projecting your PC screen!



3.5.11 Make WPS Token

Click **"Make WPS Token"** to make a USB WPS Token, you can insert a USB thumb drive and follow the wizard to make the Token.


USB Auto Setup Wizard
USB Auto Setup Wizard
This wizard helps you set up a USB Token which you can perform Plug and Show through this USB token.
To continue, click Next.
< Back
Next >
Cancel


USB Auto Setup Wizard
Plug your flash drive into any USB port on this computer, and wait for the drive letter to appear below.
Flash Drive :
F:\
All
< Back
Next >
Cancel

3.5.12 Copy Application to desktop

Click the **"Copy Application to desktop"**, it will copy the application to your desktop immediately even you don't have the system privilege



3.5.13 Hot Key

Click **"Hot Key"** to show Hot Key guide. You can use hot key to control the projection by keyboard.




Hot Key
Full Screen: Ctrl + Shift + F
Split # 1: Ctrl + Shift + 1
Split # 2: Ctrl + Shift + 2
Split # 3: Ctrl + Shift + 3
Split # 4: Ctrl + Shift + 4
Stop: Ctrl + Shift + S
Pause: Ctrl + Shift + P
Menu: Ctrl + Shift + M
Speedy mode: Ctrl + Shift + T

3.5.14 About

Click **“About”** to show system information. It includes product model name, Client version, IP address and other information.



3.5.15 Exit

Click **“Exit”** to exit this application. It will stop current playing status and close the application immediate.



4. Mac Client Utility

4.1 Launch Application

1) Enable your WiFi and connect to WPS device.
2) Execute WPS client software for Mac.

3) Launch WPS software and enter the login code.

4) Start Projection.

4.2 Main User Interface



4.3 Screen Projection

Click the “Play” button for full or split screen, you can project the main screen on to the display immediately, click the “Pause” button, you can freeze you projection

screen, and click the “Stop” button to stop projecting your screen.

Button	Description
	Full Screen projection
	Project to Split #1
	Project to Split #2
	Project to Split #3
	Project to Split #4
	Stop projecting
	Pause projecting
	Refresh Screen

5. Web Management

5.1 Home Page

1. Make sure your PC connects to WPS-Dongle successfully.
2. Open your browser, it will enter WPS home page automatically.
3. If not, enter your IP address on the browser, you can see the IP on the projector screen.

4. The default IP is 192.168.100.10



5.2 Download Software

1. Select “Download software” function.
2. Please select the “Win 7 / Windows Vista / XP ” or “Windows Mobile 5/6” or “Mac Utility” and execute the installation program.
3. Follow Installation Wizard instructions to proceed until the installation process complete.
4. If pop up “**Windows Security Alert**” because Windows firewall block this program. You just press “**Unblock**” button to continue installation.
5. Once installation complete, a utility shortcut come out on the screen.



File Download - Security Warning
Do you want to run or save this file?
Name: WPS.exe
Type: Application, 1.36MB
From: 192.168.100.10
Run
Save
Cancel
While files from the Internet can be useful, this file type can potentially harm your computer. If you do not trust the source, do not run or save this software. What's the risk?

5.3 Login Web Admin

1. Click [**Admin]** and then enter password to login web page.
2. The password default value is “admin”.

5.3.1 System Status



Click **[System Status],** shows current system status.

Model Name: Product model name

Versions:

1. **Firmware version no.**: Product firmware version number.

Network Status:

1. **IP address**：IP address of WPS device.
2. **Subnet Mask**：subnet mask
3. **Default Gateway**：default gateway
4. **Wireless MAC address**：wireless MAC address
5. **Wire MAC address**：wire MAC address

Connection Status:

1. **Projecting status:** which is “Waiting for projecting” or “Projecting”
2. **Total Users:** This shows how many users are logged into WPS dongle.

5.3.2 Network Setup

There are many kinds of operating configurations as below.



< Auto-Configuration Network Setup>

The default setting of the WPS dongle is DHCP client. When the WPS dongle is connected to a LAN that already has a DHCP server present, the WPS dongle takes an IP address assigned to it by the server. When the WPS dongle is connected to a LAN that does not have a DHCP server, the WPS dongle becomes the DHCP server in the network.

< IP Setup>

- ♦ You can select “obtain IP address automatically” or “Use the following IP address”

- IP Address: The default value is 192.168.100.10.
- Subnet Mask: The default value is 255.255.255.0
- Default Gateway: The default value is 192.168.100.10
- DNS Server: The default value is 192.168.100.10

<DHCP Server Setup>

- You can select “auto(Enable/Disable DHCP Server” or “Disable”)
- Start IP: The start IP address of DHCP Server.
- End IP: The end IP address of DHCP Server
- Subnet Mask: The default value is 255.255.255.0
- Default Gateway: The default value is 192.168.100.10
- DNS Server: The default value is 192.168.100.10

< Wireless Setup>

- Wireless LAN: The default value is “Enable”.
  Embedded AP SSID:SSID string ,max. Length is 32 bytes.
- **Connect to Existing AP**: This is “AP client” mode feature. By this feature you can join others Access Point via wireless.
  First, enter the existing AP’s SSID and require security key in “**Existing AP SSID**” and “**Key**”, then reboot your system. After these steps, WPS will connect to this AP by wireless automatically.
  Note: The default value of AP client mode is “Disable”, and LAN function will be disabled during AP client mode.
- Region: default value is “Worldwide”.
- SSID Broadcast: The default value is “Enable”
- Channel: to set fixed channel or Auto. The “Auto” means after power on WPS, it will scan all of wireless channel and select clear one channel automatically.
- Encryption: you can select “Disable” or one of WEP/WPA/WPA2 64bit or 128bit in ASCII or HEX string.
- Key: If Encryption is enabled, you have to set key value according to the encryption mode you selected.

<Apply >: press button to select this mode.

<Cancel>: press button to abort action.

<Back>: Back to Operating mode main menu.

5.3.3 OSD Setup



Click **[OSD Setup]** button, to change OSD standby image.

- **<Restore Initial>**: Restore to default OSD standby image.
- **<Image File Upload>**: Upload the customized OSD standby image. (You need to convert the image to system defined format using provided IB Maker utility which is stored in the USB token.)

Click **[Screen information]** button, to change OSD information display.

- **<Disable>**: only login code (if it has)
- **<Enable>**: all information, login code, IP, SSID, Resolution, Channel, Version, Security
- **<Some Information>**: IP, SSID

5.3.4 Projection Setup



Click **[Projection Setup]** button

- **<Resolution>**:
  VGA: XGA(1024*768), WXGA(1280x800) ,WXGA (1280*768) and SVGA(800*600). The default value is XGA.
- **<Login Code>**: You can select “Disable”, “Random”, or “Use the following code” to set a specified 4-characters Number.
- **<Apply>**：Confirmation and Save modifications
- **<Cancel>:** Cancel all the modifications

5.3.5 Change Passwords

Click **[Change Password]** button, to change password value.

The length of password is up to 8 characters.

- **<Enter New Password>:** enter new password you want to change for each category.
- **<Confirm New Password>**: double confirm new password.
- **<Apply>:** Confirmation and Save modifications.

5.3.6 Reset to Default



Click **[Reset to Default]** button to restore factory default settings.

<Apply>: Confirmation and action.

5.3.7 Firmware Upgrade



Click **[Firmware Upgrade]** button to upgrade firmware.

1. Firstly, you have to get latest firmware image file from your vendor.
2. Click **<Browse>** to specify file name you want to upgrade.
3. Click **<Upgrade>** to start.
4. A warning message shown and count down counter on the screen.
5. After a few minutes, a completed message is shown on the screen.
6. Restart WPS dongle to take effect.


Wireless Presentation System
WPS > Admin > Firmware Upgrade
Please wait while System burns new firmware into your device.
Warning: It needs to take 3~4 minutes to burn the file you transferred into flash memory.During this period, any interrupt such as shut down or reboot the system will cause system crash!!
Estimated Time remaining: : 236 seconds
Copyright © 2010. All rights reserved.

Microsoft Internet Explorer
The process of firmware upgrade is complete successfully. Please turn off power switch to restart.
OK

Warning: Don't power off WPS while firmware upgrade in progress, otherwise will cause your Dongle to stop working and will need to be returned to your vendor for firmware updating.

5.3.8 Reboot System

Click **[Reboot System]** button, to restart system

- **<Reboot>**: reboot system automatically.

5.3.9 Logout


Wireless Presentation System
WPS > Admin > System Status
Logout »
System Status
Network Setup
OSD Setup
Projection Setup
Change Passwords
Reset to Default
Firmware Upgrade
Reboot System
Model Name
WPS-Dongle 2
Versions
Firmware Version
1.0.0.0
Network Status
IP Address
192.168.0.104
Subnet Mask
255.255.255.0
Default Gateway
192.168.0.1
Wireless MAC Address
00:12:5F:02:B9:0C
Connection Status
Projecting Status
Waiting for Projecting
Total Users
0
Copyright © 2011. All Rights Reserved

6. Appendix

Screen Image Background Maker

Quick Installation Guide

Version: 1.00

1) Run the “Screen Image Background Maker” and ~~follows~~ follow the wizard to convert the image file.


Setup - Screen Image Background Maker
Welcome to the Screen Image Background Maker Setup Wizard
This will install Screen Image Background Maker 1.0.0.0 on your computer.
It is recommended that you close all other applications before continuing.
Click Next to continue, or Cancel to exit Setup.
Next >
Cancel

2) Press “Open” to select a file to convert this image for background use.


Screen Image Background Maker
Open
Save
[Please select a source image for the projection screen image.]
The image preview created here is displayed.
You can also drag a file to display it.
Resolution of converted image will be 800 by 600 pixels.
Image size and aspect ratio would be changed.
Clicking the Save button saves the image that has been created. The original image is not ch
About Screen Image Background Maker



3) Press “Saver” to save this file.(*.ib)



4) Please connect to WPS webpage, and then connect to OSD setup page.



5) Press “Browser” to choose the *.ib file.





6) Press “image file upload” to upload your background image.
Then it will show the message as below.



Note: You may find “Screen Image Background Maker” in the USB Token.